

外形安装尺寸  
Mounting Dimension Sheets-overview

**F87**

**FA87/FAF87/FAZ87空心轴 /Hollow shaft**

**F..T87**

**FA87**

**FAZ87**

**FF87**

**FAF87**

电机需方配或配特殊电机时需加联接法兰

**F..87R57**

**F..S87**

注: 其余尺寸见相对应结构形式  
Note: For other values please refer to the opposite structure.

When equipping the user's motor or the special one, the flange is required to be connected.

Y2电机机座号 Motor size	80	90S	90L	100	112M	132S	132M	160M	160L	180M	180L
功率/4P Power/(kW)	0.75	1.1	1.5	2.2	3	4	5.5	7.5	11	15	22
L3	246	280	304	350	380	425	461	524	547	583	616
G	175	195	195	215	240	275	275	330	330	380	380
L2	86	86	86	71	71	101	101	126	126	126	126

注:1. 以上壳体为通用件, 安装尺寸均可相互参照 2. "F.."表示F、FA、FF、FAF、FAZ  
Note: 1. The above housings are common parts. The mounting dimensions may consult each other. 2. "F.." mean F、FA、FF、FAF、FAZ